



BOILER MODEL IDENTIFICATION

All Dynatherm™ boiler models are identified by a serial number and usually begin with an alphabetical prefix (Example: FP3421). The following list defines the serial number notations for each model produced since 1937 for which parts are still available.

<u>MODEL</u>	<u>YEARS MFD</u>	<u>GENERAL DESCRIPTION</u>
Series 1945	1937 - 1947	Original two-pass Dynatherm. Serial number without a prefix. <ul style="list-style-type: none">• <i>Example: 3421</i>
Series 1945	1947 - 1948	First three-pass Dynatherm, belly flue. Serial number prefixed with 0. <ul style="list-style-type: none">• <i>Example: 03421</i>
Series 10	1948 - 1949	Series 10 Dynatherm. Serial number prefixed with 10. <ul style="list-style-type: none">• <i>Example: 103421</i>
RB	1950 - 1964	Revised belly type. Serial number prefixed with RB. <ul style="list-style-type: none">• <i>Example: RB133421</i>
FP	1965 - 1974	First FP series model. Serial number prefixed with FP. <ul style="list-style-type: none">• <i>Example: FP3421</i>
CC	1974 - 1976	CC Model. Serial number prefixed with CC. <ul style="list-style-type: none">• <i>Example: CC3421</i>
FPA	1976 - 1977	FPA Model. Serial number prefixed with FPA. <ul style="list-style-type: none">• <i>Example: FPA3421</i>
FPB	1977 - 1988	FPB Model. First model using conventional retention head burners. Serial number prefixed with FPB. <ul style="list-style-type: none">• <i>Example: FPB3421</i>
FPC	1988 - 1990	Dynatherm FPC. Serial number without a prefix. <ul style="list-style-type: none">• <i>Example: 3421</i>
FPC	1991 - 2008	Dynatherm FPC. Serial number prefixed with C. <ul style="list-style-type: none">• <i>Example: C3421</i>
FP	2008 - present	Manufactured by Dynatherm™. Serial number prefixed with C. <ul style="list-style-type: none">• <i>Example: C3421</i>

NOTE: For all ASME boilers, the serial number is prefixed with the last two digits of the year the boiler was manufactured. (*Example: 16CV3421*)
